

Installation Instructions for the GF-16

A - Using a stud finder, determine the center of the studs and mark each stud and then the center between them.

B - Then measure about 18" from the ceiling and draw a mark in the center so that you make the cross as drawn.

C - Draw a 14.5" circle from the center point. Drill out the center point all the way through the outside wall.

D - Draw a 14" square on the out side centered on the pilot hole. Cut out each side with your drywall saw and or saws-all.

Next install the GF-16 fan into the round hole and secure into the studs. Do the same with the grill on the out side with face pointing down.

Center the intake grills in the raised panel in the garage door. Trace the inside of the intake grill with a pencil and drill each corner with a 1/2" drill so you can get tin snips in and cut out the hole. Screw or pop rivet the intake vents on to the door. Place one on each end of the garage door and in the bottom panel for maximum air flow.

Please call 480-217-8734 for any tips on the GF-16 Garage Fan Installation.

Thank You For Your Purchase - Enjoy!

